Content

Vinyl

Backing

Hi-Loft^{2™}

00% Polyester

DEDI (A DI OV

PERMABLOK PLUS+

Characteristics

Bleach Cleanable (1:9)**

Cleanable

Denim Dye Cleanable

Sulfide Stain Resistant

Water Resistant

Environmenta

AB 2998 Compliant

Formaldehyde Free

No Biocides

No Flame Retardants

No Heavy Metals

140 Ficary Fictals

Prop 65 Compliant Performance

Anti-static

Cold Crack -20°F

CFFA-6a

Sulfide Stain Resistant

Fisher Body TM 31-12

Superior Abrasion

CFFA-1a / ASTM D-4157 100,000 Cycles, Wyzenbeek #10 Cotton Duck

UV Stability

Xenotest: AATCĆ TM 16-3 / NTC 1479 / CFFA-2a - Blue Wool 1,000 Hours



This fabric meets or exceeds these ACT performance guidelines.
Certification Marks owned by ACT



Flame Retardancy*

California T.B. 117 - 2013

NFPA 260 - Cover Fabric - Class I

UFAC Fabric - Class I

*This term and any corresponding data refer to the typical performance in the specific tests indicated and should not be construed to imply the behavior of this or any other material under actual fire conditions.

Specifics

Weight: 27 oz.

Width: 54 in.

Roll Size: 30 yd.

Applications

- ☐ Automotive | RV
- ☑ Education
- ☑ Healthcare
- ☑ Office

Hospitality

- ☑ Hotel | Motel | Casino
- ☑ Restaurant
- ☑ Public Spaces

Marine

- ☑ Interior
- ☐ Exterior

Residential

- ✓ Interior
- ☐ Exterior

PERMABLOK PLUS+ CLEANING GUIDE



We recommend cleaning at least once a week to extend the lifespan of the upholstery, which will prevent dirt and contamination buildup and permanent staining. In the event of a spill, wipe off any excess right away with a dry white cloth or fabric, but careful not to spread to remaining surface.



Clean the whole surface in a circular motion using liquid hand soap (pH neutral) and water (1 part soap to 9 parts water). Check the Approved Cleaners guide for recommended cleaning products. Wipe with a clean damp cloth to get rid of any excess soap. Repeat as needed and then let dry.



If there is any buildup that cannot be removed with soapy water, a mixture of I part isopropyl alcohol to 9 parts water can be used as a last resort. (Remember, using alcohol on a regular basis can affect the properties of the product).



Once a month, you can use a soft-bristle brush for a deeper cleaning. Remember, light colors need more care, more often.

Note: The cleaning products recommended were used in a laboratory setting. Spradling Group® has no relationship with the manufacturers of those cleaning products.

**Disinfectants

In addition to cleaning, healthcare facilities maintain disinfecting regimens to reduce the spread of infections. There is a wide variety of available biocides that include bleaches, peroxides, and quaternary ammonium products, among others. They should always be used at the recommended dilution, never in concentrated form. To prolong the life of coated fabrics, the disinfectants should be rinsed off after each use. It should be noted that misuse of disinfectants is the major source of surface deterioration. Spradling International, Inc.® continually evaluates cleaners/disinfectants, and a list of those tested can be found on our website.

Abrasion test results exceeding ACT Performance Guidelines are not an indicator of product lifespan. Multiple factors affect fabric durability and appearance retention.

PERMABLOK® PLUS+ is a registered trademark of Spradling Holdings, Inc. WHISPER™ NEO PLUS is a trademark of Spradling Holdings, Inc.

©2021 Spradling International, Inc.®

8/2021



SPRADLING INTERNATIONAL, INC.®

200 CAHABA VALLEY PARKWAY P.O. BOX 1668 | PELHAM, AL 35124

PHONE 800-333-0955

FAX 205-985-2354 | 205-985-9176 EMAIL orders@spradling.group

WWW.SPRADLING.GROUP

USA LOCATIONS

Pelham, Alabama Fullerton, California Grand Rapids, Michigan Westampton, New Jersey Maryville, Tennessee

INTERNATIONAL LOCATIONS

Europe (Spain | UK | Germany)

Mexico



